

PRODUCT LIST - F1 INKS MANUFACTURED BY MALINDO IMAGING TECHNOLOGIES

OEM Code	Printer Model	F1 Code	Color				
Brother							
LC-41 / LC-47 / LC-57	MFC-3360C / 620CN / 5440CN / 210C / DCP-110C	F1-BIBKP9	●				
		F1-BIBK156	●				
LC-41 / LC-47 / LC-57	MFC-210C / 410C / 620CN / 3240CN / 5440CN / 5840CN DCP-110C / FAX-1840C	F1-BIC94	●				
		F1-BIM95	●				
		F1-BIY96	●				
Canon							
BC-20 / 01 / 02 / BX-2	BJC-2100 / BJC-4000 / BJC 1000 / 650c/PS	F1-CIBKP3	●				
		F1-CIBK152	●				
CANON PG 40 / PG 830 / PG 50 / BCI-24	PIXMA MP150 / MP450 / iP1200 / iP1300 / iP1880 / iP6220D	F1-CIBKP6	●				
		F1-CIBK157	●				
BCI-3eBk / PGI-5Bk	Canon i850 / i860 / BJC 3000 / 6300 / S400 / IP 4000	F1-CIBKP7	●				
		F1-CIBK153	●				
BCI-15 / BCI-16Bk	Pixma i70 / Pixma i80 / iP 90 / 90v	F1-CIBKP8	●				
		F1-CIBK154	●				
Canon BCI-10Bk / BCI-11Bk / BCI-21Bk	BJC-70 / 80 / BJC 2100	F1-CIBK52	●				
		F1-CIC53	●				
BCI-11 / BCI-21	BJC-70 / 80 / BJC 2100	F1-CIM54	●				
		F1-CIY55	●				
BC-03 / BC-02 / BX-3	Canon BJ200 / BJ230 / BJC210S / 210SP / 1000SP / 265 / 255	F1-CIBK56	●				
		F1-CIC57	●				
BCI-3	Canon i850 / i860 / BJC 3000	F1-CIM58	●				
		F1-CIY59	●				
		F1-CIPM60	P●				
BCI-3 / BCI-5 / BCI-6 / CLI-8 Bk	Canon Pixma iP8500 / i900 / i905D / i9100	F1-CIPC61	P●				
		F1-CIPBK62	P●				
		F1-CIC63	●				
BCI-5 / BCI-6	Canon Pixma iP8500 / i900 / i905D Canon i950 / i905D Canon Pixma i960 / i965	F1-CIM64	●				
		F1-CIY65	●				
		F1-CIPM66	P●				
		F1-CIPC67	P●				
CLI-8	Canon Pixma iP3500 / iP4200 / iP4500 Canon Pixma iX4000 / iX5000	F1-CIC70	●				
		F1-CIM71	●				
		F1-CIY72	●				
		F1-CIPC73	P●				
BCI-15 / BCI-16	Canon Pixma i70 / i80 / iP90 / 90v	F1-CIPM74	P●				
		F1-CIC75	●				
		F1-CIM76	●				
		F1-CIY77	●				
BCI-24C	Canon Pixma iP1000 / iP1500 / S200 / S300 / i255 / i455 / i475	F1-CIC78	●				
		F1-CIM79	●				
		F1-CIY80	●				
BC-05	BJ-200 / BJC1000 / 210 / 240 / 255	F1-CIC81	●				
		F1-CIM82	●				
		F1-CIY83	●				
CL-41 / CL-831 / CL-51	PIXMA iP1200 / 1300 / 1880 / 6220D PIXMA MP 150 / MP 450	F1-CIC87	●				
		F1-CIM88	●				
		F1-CIY89	●				
Epson							
T-003 / T-007 / T-038 / T-013 / T-015 / T-017 T-019 / T-026 / T-028 / T-0491 / T-0761 S020010 / S020047 / S020189 S020118 / S020108 / S020138 S020025 / S020032 / S20187 / S020093	Stylus Color C41 / C43 / C45 / 900 / 790 / 870 / 1290 / C20SX Stylus Color 680 / 777 / 2000P / CX1500 / C60 / C61 / CX3100 Stylus Color II / 810 / 820 / 830 / 935 / R210 / R230 / RX510 Stylus Color 300 / 440 / 460 / 640 / 660 / 670 / Stylus C58 Stylus 1000 / CX2800 / 1520 / 400 / 500 / 600	F1-EIBK101	●				
				T-014 / T-018 / T-020 / T-029 / T-037 / T-039 S020097 / S020191 / S020089 / S020138 / S020049 S020066 / S020036	Stylus C20UX / C480 / 580 / C40 / 1160 Stylus 820 / Stylus Color 400 / 600 / 800 / 850 / 1520 Stylus 200	F1-EIC102	●
						F1-EIM103	●
						F1-EIY104	●
				T-0491 T-0492 T-0493 T-0494 T-0495 T-0496	Stylus Photo R210 / R230 / R310	F1-EIBK105	●
F1-EIC106	●						
F1-EIM107	●						
F1-EIY108	●						
F1-EIPC109	P●						
		F1-EIPM110	P●				

OEM Code	Printer Model	F1 Code	Color
T-027 / T-008		F1-EIC111	●
T-009 / T-016	Stylus Photo 810 / 830 / 1200 / 1280 / 1290	F1-EIM112	●
T-001 / T-005	Stylus Photo 875 / 790 / 890 / 700 / 720	F1-EIY113	●
S020110	Stylus Photo 915 / Stylus Color 900 / 935	F1-EIPC114	P●
S020193		F1-EIPM115	P●
T-0731		F1-EIBKD132	●
T-0732	T11	F1-EICD133	●
T-0733		F1-EIMD134	●
T-0734		F1-EIYD135	●
HP			
HP-C6614A / HP-51629A	HP DJ-610 / 640C / 630C / 660 / 656C / 690C / 692C / 3820	F1-HIBKP1	●
HP-C6615A / HP-51645A / HP-51640A	HP DJ 710 / 810 / 840 / 845 / 920 / 1600 / 6122 / 9300	F1-HIBK155	●
	HP DJ 1200 / Designjet 230 / 330 / 350c / 430 / 450a / 650/PS		
HP-C8727A / HP-C6656A / HP-C9351A (21)	HP-DJ 3320 / 3325 / 3550 / 5150 /D1360 / 3920 / 4260	F1-HIBKP5	●
HP-C8765W (94) / HP-C8767W (96) / HP-CB 335W (74)	HP-DJ 7260 / HP-Photosmart 5550 / 1402 / 1410	F1-HIBK158	●
HP-C9362W (92) / HP-C9364W (98)	PSC-F380 / 5440 / 6540 / HP-DJ 8450 / 6840 / 7210		
HP-51626A / 33M	Apollo 1200 / 300 / 400 / 500 series	F1-HIBK10	●
	HP-Business Inkjet 1000 / 1100 / 1200 / Designjet 800 / 500 / 100	F1-HIC11	●
HP-C4841 / 42 / 43A (10)	Colorpro / Copier cc800 / Designjet Colorpro / Bj2000 / 2500	F1-HIM12	●
		F1-HIY13	●
HP-C4836 / 37 / 38A (11/13)	HP-Business Inkjet 1000 / 1100	F1-HIC14	●
HP-C4804 / 05 / 06A (12)	HP-Designjet 500	F1-HIM15	●
HP-C4911 / 12 / 13A (82)	HP-Designjet 500PS	F1-HIY16	●
		F1-HIC23	●
HP-51625A	Apollo 1200 / 300 / 400 / 500 series	F1-HIM24	●
		F1-HIY25	●
	HP-DJ 610C / 660 / 670	F1-HIC20	●
HP-51649A	HP-DJ 630C / 656 / 695	F1-HIM21	●
	HP-DJ 640 / 690 / 692	F1-HIY22	●
HP-C6578A	HP-DJ 930C / 950C / 970CXI / 990CXI	F1-HIC26	●
	HP-Officejet 725 / 5110	F1-HIM27	●
		F1-HIY28	●
HP-C1823A / HP-51641A	HP-DJ 880 / HP-DJ 890 / HP-DJ 710 / HP-DJ 810	F1-HIC32	●
	HP-DJ 850 / HP-DJ 855 / HP-DJ 830 / HP-DJ 1120 / 1125	F1-HIM33	●
	HP-DJ 870 / HP-DJ 1000cxi / HP-DJ 1150c	F1-HIY34	●
HP-C6625A		F1-HIC35	●
	HP-DJ 840C / 845C	F1-HIM36	●
		F1-HIY37	●
HP-C8728A	HP-DJ 3320 / 3325 / 3550 / 5150	F1-HIC38	●
HP-C6657A	HP-Photosmart 7150 / 7155	F1-HIM39	●
HP-C9351A (22)	HP-Officejet 4110 / 6110 / PSC 2150 / 2210 / 1210	F1-HIY40	●
HP-C8766W (95) / HP-CB337W (75)	HP-DJ 460 / 5740 / 6540 / 6840 / 9800 / PCS 1600 / 2350 / 6210	F1-HIC43	●
HP-C9363W (97)	HP-DJ 5400 / PSC 1610 / OJ 6205 / 2355	F1-HIM44	●
HP-C9361W (93)	HP DJ 4200 / 8150 / 8450 / 7310 / 7410	F1-HIY45	●
Lexmark			
LEX-13400HC / 17G0050/55	LEX-Z32 / LEX-Z22 / LEX-Z515 / LEX-Z25	F1-LIBKP2	●
LEX-12A1970 / 75 / 10N0016		F1-LIBK159	●
LEX-10N00217 / 13620HC			
LEX-10N0026 / 227 / 15M0120	LEX-Z25 / LEX-Z515 / LEX-Z12 / LEX-Z22 / LEX-Z32	F1-LIC29	●
LEX-12A1980 / 13619HC / LEX-17G0060 / 65	LEX-Z32 / LEX-Z22 / LEX-Z605 / LEX-Z615 / LEX-Z31	F1-LIM30	●
		F1-LIY31	●
Miscellaneous			
		F1-EIBK97	●
Cleaning Solvent for Epson		F1-EICL98	●
		F1-EIML99	●
		F1-EIYL100	●

Sold in bottles: 100 ml, 1 kg, 5 kg and 20 kg